

Albedo Neutron Dosimeter



Albedo Neutron Dosimeter with TLD Cards


Albedo neutron dosimeters measure indirect neutrons, scattered by the human body, creating a neutron flux of thermal and albedo neutrons at the surface of the body. They have been found to be the only dosimeters which can measure doses due to neutrons over the whole range of energies.

Further the boron-loaded plastic encapsulation allows the simultaneous measurement of beta dose, gamma dose and neutron dose.

Two types of Lithium Fluoride are used to separate doses contributed by gamma-rays and neutrons. MTS-6 (enriched in ^6Li and very sensitive to thermal neutrons) and MTS-7 (containing very little of ^6Li and has a negligible neutron response).


^6LiF has one of the highest thermal neutron sensitivity of any phosphors. Most of the neutrons will be absorbed inside the MTS-6 pellet within a few 0.1 mm of penetration.

However, because of their enhanced response to neutrons of lower energies, there may be a need for an additional field measurement which allows correction for this energy response.



Above: Albedo Holder for Harshaw type TLD card


Right: Albedo Holder for Rados type TLD card



Technical Specifications

Material	Boron Loaded Plastics with beta window in the front and Albedo window in the back side
TLD Cards	4-element Harshaw TLD Card, LiF:MgTi, type 6776 (MTS-600 / MTS-700)
	Rados TLD Card with 4 elements, LiF:Mg,Ti, type 7667 (MTS-6 / MTS-7)
Measured doses:	
Position 1	gamma deep dose with ^7LiF
Position 2	Albedo neutrons with ^6LiF
Position 3	thermal neutrons with ^6LiF
Position 4	beta-gamma skin dose with ^7LiF

Accessories



Opening Tool



TLD Card, Type Rados



TLD Cards, Type Harshaw

All information in this brochure is subject to technical changes without notice.

RadPro International GmbH
...Radiation Protection for the Radiation Professionals...
 An der Hasenjagd 7
 42897 Remscheid
 Germany
 Phone: +49 2191 69104-0
 Email: sales@radproint.de
 Web: www.radpro-int.com

